

# OPTIC PLUS



#### Contact

@moxlite.prolight  
+62 859 2122 1107  
info@moxlite.com

#### HQ & Workshop

Global Multipro Technology  
Rukan Crown B no. 25  
Greenlake City, Cipondoh, Tangerang

## User Manual

KEEP THIS MANUAL FOR FUTURE NEEDS

[www.moxlite.com](http://www.moxlite.com)

## MENU OPERATIONS

Addr	A(001-512)	
CHAN	CH04	
	CH09	
STAT	WHI1	0-255
	WHI2	0-255
	WHI3	0-255
	WHI4	0-255
	Strb	0-255
AUTO	Aut1	SP-(1-9)
	Aut2	
	Aut3	
	Aut4	
SOUD	SOUD1	SC-(1-9)
DIM	OFF	
	DIM1	
	DIM2	
	DIM3	
	DIM4	
REST	NO	
	YES	
Ver	V001	

## DMX CHANNELS

4CH	Function	DMX Value	Description
1	WHITE1	0-255	0-100%
2	WHITE2	0-255	0-100%
3	WHITE3	0-255	0-100%
4	WHITE4	0-255	0-100%
9CH	Function	DMX Value	Description
1	DIMMER	0-255	0-100%
2	STROBE	0-9	No Function
		10-255	strobe speed slow to fast
3	WHITE1	0-255	0-100%
4	WHITE2	0-255	0-100%
5	WHITE3	0-255	0-100%
6	WHITE4	0-255	0-100%
7	Macro	0-255	MACRO
11	Auto	0-9	CH1-CH6 Control
		10-144	Choice,CH7 Control
		145-164	Auto 1
		165-184	Auto 2
		185-204	Auto 3
		205-224	Auto 4
		225-255	Sound
		0-255	Auto Speed from slow to fast
12	Speed	0-255	Auto Speed from slow to fast

## **MAINTENANCE AND CLEANING**

The following points have to be considered during the inspection:

- 1) All screws for installing the devices or parts of the device have to be tightly connected and must not be corroded.
- 2) There must not be any deformations on the housing, color lenses, fixations and installation spots (ceiling, suspension, trussing).
- 3) Mechanically moved parts must not show any traces of wearing and must not rotate with unbalances.
- 4) The electric power supply cables must not show any damage, material fatigue or sediments.

Further instructions depending on the installation spot and usage have to be adhered by a skilled installer and any safety problems have to be removed.



### **CAUTION**

Disconnect from mains before starting maintenance operation.



In order to make the lights in good condition and extend the life time, we suggest a regular cleaning to the lights.

- 1) Clean the inside and outside lens each week to avoid the weakness of the lights due to accumulation of dust.
- 2) Clean the fan each week.
- 3) A detailed electric check by approved electrical engineer each three month, make sure that the circuit contacts are in good condition, prevent the poor contact of circuit from overheating.

We recommend a frequent cleaning of the device. Please use a moist, lint- free cloth. Never use alcohol or solvents.

There are no serviceable parts inside the device. Please refer to the instructions under "Installation instructions".

Should you need any spare parts, please order genuine parts from your local dealer.